Welcome to Prijector

INSTRUCTIONAL MANUAL

COMPANION & DESKTOP MODE

Prijector

www.prijector.com

Things to Know

- Prijector and your laptop should be on the same subnet

- Same network different subnet click here
  http://prijectr.com/support/knowledgebase.php?article=31&suggest=1

- For VGA connection buy a HDMI to VGA Adapter
  (Ignore if you are connecting to HDMI)

- HDMI IN is for integrating your video conferencing equipment.
  (Ignore if you dont have Video Conferencing Equipment)

- You need Remote Control Or Standard Computer Mouse to setup
  Prijector for the first time

- For Video Manuals and how to use Remote Control click here
  https://prijector.com/installationvideos/index

Prijector Ira 7.1   — ✕

Stop

☐ Video Service

QUALITY SETTINGS ❓

⚪ HIGH   ⚫ BEST   ⚪ LOW

MEDIA SHARING ❓

Enter Youtube URL

You Tube   🎵📹🎞️

≪   ■   ▶   ≫ | −   🔊   +

PRESENTATION / VIDEO CONFERENCING

▶📊   ↗

Connected to **PRIJECTOR0ab6**

— Close/Minimize

— Share/Stop

— Quality Settings

— Videos

— Mode Controls

— Prijector SSID

Prijector Ira 7.1

Stop

☐ Video Service

QUALITY SETTINGS ❓

● HIGH   ● BEST   ● LOW

MEDIA SHARING ❓

Enter Youtube URL

You Tube

⏪ ⏹ ▶ ⏩ − 🔊 +

PRESENTATION / VIDEO CONFERENCING

Connected to **PRIJECTOR0ab6**

Click to Share/Stop

Paste Youtube URL

Select Local Media Files ⎤ Videos

Media Controls

External Equipment

Screen Share